

Cementex TruFit® Leather Protectors

Quality Leather protectors result in better dexterity, comfort, and safer working conditions for qualified workers. This fact has driven Cementex to create our TruFit® Leather Protectors. By using only premium materials and a new, more ergonomic design, we have created a safe and comfortable solution to energized work requirements. The newly designed palm and 3D-fingers create a more conforming fit around rubber gloves, reducing hand fatigue and greatly improving dexterity.

To get the utmost protection and life from rubber gloves, leather protectors should always be worn over the rubber gloves, while in use.

Leather protectors are to be used for the mechanical protection of rubber gloves and shall not be used alone for electrical protection per ASTM F696 (our TruFit® Leather protectors comply/exceed).

Warning! Do not use leather protectors alone for protection against electric shock. Serious injury or death will result. Always use a properly rated insulating glove for the voltage being worked.

Arc Flash Protection - per NFPA 70E Rubber insulating gloves with protectors provide arc flash protection in addition to electric shock protection. Higher class rubber insulating gloves with protectors, due to their increased material thickness, provide increased arc flash protection.

TruFit® Low Voltage Leather Protectors are constructed of Premium Top Grain Goat Hide providing a soft, flexible feel and excellent protection.

- Whole Sizes 8-12 (complementary fit for associated half sizes)
- 10" Overall Length (OAL)
- Designed for use over Class 00 and Class 0 Insulating Rubber Gloves
- Cinch Strap style is standard for kits*

*transition based on inventory levels of elasticized style

TruFit® High Voltage Leather Protectors are constructed of Premium Top Grain Cow Hide providing a soft feel and our highest level of protection.

- Features Wrist Cinch Strap
- Whole Sizes 8-12 (complementary fit for associated half sizes)
- 12" Overall Length (OAL)
- Designed for use over Class 1, 2, 3 and 4 Insulating Rubber Gloves



Part Number	Description
P0-10-(size)*	Class 00/0: 10" OAL TruFit® Protector
P0-10-(size)CS	Class 00/0: 10" OAL TruFit® Protector with Cinch Strap
P2-12-(size)	Class 1/2/3/4: 12" OAL TruFit® Protector

**NOTE: TruFit® Protectors without Cinch Strap will be available in limited sizes and/or quantities while transitioning to cinch strap style only.*

Leather Protectors Clearance Per ASTM F496 (Table 4)	
Glove Class	Minimum Distance Between Protectors & Gloves
00/0	1/2" / 13mm
1	1" / 25mm
2	2" / 51mm
3	3" / 76mm
4	4" / 102mm